

Store this page in the front pocket for quick reference.

For use on private land - Before using read the safety instructions, read user manual and watch the instructional videos. Practice operating methods in a safe and clear location before using in a professional environment. Users accept all liability for use.




Safety Notice

After-sales support: support@zilrpro.com


- Legal Compliance:** Legal Compliance: Users must comply with all local laws and regulations. Do not operate the cart in prohibited areas. In jurisdictions where no specific regulations govern electric utility carts, strictly adhere to the safety guidelines and the user manual. Failure to comply may result in property damage, personal injury, or legal penalties. ZILR PTY LTD, and its affiliates shall not be liable for any such damages or penalties.
- Skill Requirement:** Ensure you have practiced and mastered essential operation skills before using the Cart. The company shall not be liable for any injuries or damages resulting from improper use.
- User Eligibility:** Suitable for riders aged 16 to 60, with a height over 4.6 ft (1.4 m) and a weight between 88 and 243 lbs (40–110 kg); riding is prohibited for those outside these limits, as well as for individuals under the influence of alcohol or drugs, those with medical conditions restricting physical activity, those unable to maintain balance, pregnant women, individuals with disabilities, or anyone with impaired reflexes.
- Recommended Use:** Only Recommended Use: Private land with correct permission (such as compounds, dedicated venues, stadiums, studio lots or private festival sites).
- Safety Precautions:** Do not modify the front seat mounting holes, and always ensure both locking pins are fully inserted through the support rods and visibly exposed before riding; do not ride if the seat is not securely locked, and when riding with an empty Cart, sit central and as far back as possible while ensuring effective use of the mechanical brake to prevent forward weight shift.
- Safety Check:** When riding, recommended to wear protective gear clothing/ safety gear. Do not wear sandals or open-toe footwear. Wear stiff, flat-soled shoes to ensure proper brake function.
- First Use:** First Use: Consider your surroundings, do not carry any loads and take your time. Set maximum speed to "L" (Low mode) and gain confidence with their operation of the cart.
- Riding Safety:** Control speed and monitor road conditions. Stay alert to avoid obstacles/potholes. Keep clear of motor vehicles and roads. Do not ride on steep slopes, cliffs, wet/slippery surfaces, or hazardous areas. Avoid low-light conditions, and rain/snow.
- Sharing Rules:** New riders must: read the safety notice and watch tutorial videos, master operation skills, and wear protective gear. Minors must be supervised by adults at all times.
- Warning:** Avoid sudden acceleration or deceleration. Do not exceed the rated maximum speed to prevent brake failure, loss of control, collisions, or falls.
- Pre-Ride Inspection:** Check all screws for looseness or detachment. Inspect the connecting rods at the bottom of the steering rod for cracks, looseness, deformation, or pin dislodgement. If there is unusual noises, odors, smoke, or alarm sounds, stop using it and contact the dealer. Do not use the Cart if it is malfunctioning.
- Brake Check:** Before each ride, verify that the mechanical brake is functional. If reduced responsiveness is detected, adjust or replace the brake pads according to the user manual until proper sensitivity is restored. Do not use the Cart until braking performance is fully recovered.
- Obstacle Warning:** Do not ride over obstacles higher than 0.79" (20 mm) (e.g., curbs or protrusions) to avoid tipping or falls. For proper obstacle-crossing techniques, refer to the instructional video.
- Downhill Safety:** To prevent tipping caused by forward weight shift - All items must be placed near the rear of the Cart and securely fastened to avoid shifting the center of gravity; if items cannot be secured, do not ride. Maintain a speed under 6 mph (10 km/h) and carefully observe the road surface to avoid bumps and obstacles.
- Downhill Riding:** Use the brakes to control speed when riding downhill. Do not coast or use full throttle on descents. Riding is prohibited on steep slopes with a grade of 15% or more, and the reverse riding function must not be used on slopes or ramps to avoid danger.
- Speed Limiting & Braking:** The 2WD and 4WD models are equipped with a speed-limiting system that triggers automatic braking when the speed reaches or exceeds 12 mph (19 km/h); the braking force is strong, so full-throttle acceleration or overspeed riding on downhill slopes is strictly prohibited, as it may cause tipping. Note that if the vehicle accelerates too quickly or due to other factors, the automatic braking may not engage immediately or may be delayed—therefore, always control your downhill speed.
- Load Limits:** Do not exceed the maximum load rating specified in the user manual. Reduce load when riding on slopes. Use cargo net and strap accessories to secure loads.
- Battery for Slopes:** Ensure the battery is sufficiently charged before riding on slopes. Avoid riding on slopes when battery power is low, as performance may be reduced.
- Safety:** When riding, respect others and pass them safely. Keep a safe distance on the appropriate side and slow down to avoid startling them. When approaching from behind, alert pedestrians in advance using an audible warning and reduce speed while passing.
- Braking Awareness:** The Cart's braking distance varies depending on road friction, slope angle, load weight, and tire wear. Higher speeds require longer stopping distances and increase risks. Always stay alert, monitor road conditions, maintain controlled speed, and keep safe distances from others.
- Foot Brake Alert:** This Cart features electronic assistance systems (including regenerative braking, cruise control, hill assist, and automatic speed limiting), which may fail due to system malfunctions or power loss. Never rely solely on these functions. You must maintain full control, monitor system status, and intervene when necessary. Always keep your foot on the mechanical brake pedal and practice using foot brake to ensure safety and emergency responsiveness.
- Motor Overheat Warning:** The wheel motor features overheat protection. Prolonged uphill riding with heavy loads or operation on soft surfaces may cause excessive motor heating. If the system alerts to overheating, immediately switch to towing mode or cease operation to allow cooling. Do not operate under overload conditions.
- Parking:** When parking the deployed Cart, fully depress the mechanical foot brake and verify the lever is securely locked in parking mode (dashboard icon  illuminated) to prevent rolling or unintended movement.
- Transport/Storage Mandate:** For transportation, always fold and lay the Cart flat inside the car, securing it properly to prevent tipping during bumps. Keep it away from children when storing to avoid injury.
- Modification Warning:** Unauthorized modifications may impair Cart performance, cause damage or personal injury, and void the warranty.
- Wheel Cover Safety Notice:** If the rubber cover on the outer side of the wheel falls off, is damaged, or is missing, please contact the dealer to purchase and install a replacement. Avoid exposing the wheel nuts to prevent injury to pedestrians or damage to obstacles.
- Riding Position Warning:** Never place feet inside the Cart frame or Never stand while the cart is moving. All occupants must remain seated.
- Floor board Use Warning:** Before using the Cart, fully unfold and lay the folding floor board flat inside the cabin. Do not stand in the frame while the Cart is in motion, as the floor board has a limited load capacity.
- Risk Acknowledgement:** Following safety instructions reduces but cannot eliminate all risks. When riding, you may still face injury risks from loss of control, collisions, falls, or others' violations - similar to other transportation methods.
- Cruise Control:** May exist in internal or development firmware but is not intended for manual activation. It is disabled by default and only available internally or in certain regions.

Button Interface, Control Definitions and Special Notes

Riding Mode



Towing Mode



Instrument Panel Symbol Reference

	Headlight Status
	Temporary/ Emergency Braking
	Mechanical Brake
	Towing Mode
	Both left/right levers control throttle
	Towing Cruise Mode
	Both levers adjust set speed
	L Low-Speed Mode
	H High-Speed Mode
	4WD Four-Wheel Drive Mode
	RWD Rear-Wheel Drive Mode
	FWD Front-Wheel Drive Mode

Button Function Instructions



Function Button

Riding Mode

Short Press: Engage/disengage auto-cruise (where available)
E-brake/throttle can also exit
Long Press (hold): Switch between L and H modes

Towing Mode

Short Press: Activate/deactivate towing cruise control
Hold Press: Temporary brake/release to cancel braking)
Double Press: Emergency brake(short press to release braking)



Light Button

In Any Mode

Short Press: Turn headlight ON/OFF
Long press: Turn off the front & rear logos, headlight, instrument backlight

When All the Lights Are Turned Off

Short Press: Activate lights sequentially: Instrument, Front/rear logos, Headlight



Power Button

In Riding Mode

Short press twice: Turn on Long Press: Turn off Mechanical brake + Short press to unlock/lock the throttle

While Powered On

Short press: Dim/brighten gauge


In Towing Mode Same as function key




Reverse Button

Short Press: Forward/Reverse
Long Press: Switch FWD/ RWD/4WD
(Applicable to 4WD version only)


Precautions before Riding



Precautions for Folding and Storage



Steps to Switch to Towing Mode



ZILR